



Ceiling cut out template – recessed installation




Mains supply connection – recessed installation


For stand alone and Axiom models, supplied complete with flex and plug.




For DALI models




Recessed installation



Changing trim size for non corridor models




Changing trim size for corridor models with square trim



Ensure locators are in position prior to securing the square trim



Corridor Satellite installation



NOTE: Ensure the "C₀" symbol is parallel to the wall



Minimum ceiling void

NO INSULATION



Note: Ensure emergency pack is above insulation

Surface mount installation – Direct onto the ceiling using mounting holes shown below



DALI terminal connection is applicable to DALI models only.

